


**Reloading Press
Installation Diagram**



A	CLASSIC TURRET
B	LOAD MASTER
C	APP, ACP, RELOADER PRESS
D	BL CHALLENGER
E	BL CLASSIC CAST
F	CLASSIC CAST
G	PRE 2018 PRO-1000
H	PRE 2018 3 & 4 HOLE TURRET
I	2018+ PRO-1000
J	2018+ VALUE TURRET
J	2018+ PRO-4000
K	SIX PACK PRO / PRO-6000

